

## HT4000/PB4000 JUMPER SETTING

- **JP3 : Reserved for Test (PS2 Mouse Signal loopback)**  
No PS/2 Touch Controller : Pin 1-2 Short, Pin 3-4 Short  
Through PS/2 Touch Controller : All Open
- **JP4 : 12V DC Supply Select for VGA**  
Short : 12V DC  
Open : AC
- **JP5 : CMOS DATA CONTROL**  
Pin 1-2 Short : Clear CMOS  
Pin 2-3 Short : Normal
- **JP6 : LAN CHIP CONTROL**  
Short : Enable  
Open : Disable
- **JP8 : COM1 SETTINGS**  
Pin 1-3 Short : Pin9 connected as 5V DC  
Pin 3-5 Short : Pin9 connected as RI  
Pin 2-4 Short : Pin1 connected as 12V DC  
Pin 4-6 Short : Pin1 connected as DCD
- **JP9 : COM2 SETTINGS**  
Pin 1-3 Short : Pin9 connected as 5V DC  
Pin 3-5 Short : Pin9 connected as RI  
Pin 2-4 Short : Pin1 connected as 12V DC  
Pin 4-6 Short : Pin1 connected as DCD
- **JP10 : COM3 SETTINGS**  
Pin 1-3 Short : Pin9 connected as 5V DC  
Pin 3-5 Short : Pin9 connected as RI  
Pin 2-4 Short : Pin1 connected as 12V DC  
Pin 4-6 Short : Pin1 connected as DCD
- **JP11 : COM4 SETTINGS**  
Pin 1-3 Short : Pin9 connected as 5V DC  
Pin 3-5 Short : Pin9 connected as RI  
Pin 2-4 Short : Pin1 connected as 12V DC  
Pin 4-6 Short : Pin1 connected as DCD
- **JP12 : SOFTWARE AWARENESS OF UPS STATUS**  
Pin 1-2 Short : DCD  
Pin 2-3 Short : UPS status

- **JP13 : POWER ON CONTROLL**
  - All short : w/o UPS modular
  - All open : w/ UPS modular
- **JP14 : UPS MODULAR CONNECTOR**
- **JP15 : EXTEND USB CONNECTOR**
- **JP17 : EXTEND USB CONNECTOR**

